

FITTING FROSTED WINDOW FILM

Tools required:

1. Scalpel or craft knife with a sharp blade, ruler and a pair of scissors.
2. Trigger spray bottle
3. Squeegee.
4. Bank card.
5. A cloth or kitchen towel (to mop up excess solution)

Window film application.

1. Thoroughly clean the glass. Frosted film is not suitable for exterior surfaces so must go on the inside of the glass.
2. Cut the film to size allowing an extra 10mm all round.
3. Make a solution of water and washing-up liquid (3 or 4 drops to a bottle of water) and put it in a trigger spray bottle or you can use glass and mirror cleaner in a trigger spray bottle.
4. Place the film on a flat clean surface with the backing material uppermost. Wet your fingers to prevent them from leaving finger prints on the adhesive side of the film and carefully remove the backing paper from the frosted film, spraying it with the solution as you go. (This is usually a job for two people).
5. Spray the glass with the soapy water so that it is wet all over.
6. Apply the film to the glass and slide it into position.
7. Spray the face of the film to act as a lubricant and squeegee out all the liquid from between the film and the glass. Use the credit card to get into the corners
8. Trim off any excess material using scalpel and ruler.
9. Check for air or water bubbles and squeeze them out with the bank card.
10. If any small bubbles remain when the film is dry, prick the film and squeegee the air or water out with the bank card. The film takes a couple of days to dry out completely.